FS Future Serie®

Rover C

User's manual

Any information contained in these operating instructions may be changed without prior notice.

OKM does not make any warranty for this document. This also applies without limitation to implied assurances of merchantability and fitness for a specific purpose. OKM does not assume any responsability for errors in this manual or for any incidental or consequential damage or loss associated with the delivery, exploitation or usage of this material.

This documentation is available „*as presented*“ and without any kind of warranty. In no circumstances OKM takes responsibility for lost profits, usage or data losts, interruption of business activities or all kind of other indirectly damages, which developed because of errors in this documentation.

This instruction manual and all other stored media, which are delivered with this package should only be used for this product. Program copies are allowed only for security- and savety purposes. The resale of these programs, in original or changed form, is absolutely forbitten.

This manual may not be copied, duplicated or translated into another language, neither in part nor completely, over the copyright matters without the prior written consent of OKM.

Copyright ©2002 – 2007 OKM Ortungstechnik GmbH. All rights reserved.

Contents

1 Preface **7**

2 Important Notes **8**
2.1 General Notes . . . 8
2.2 Possible Health Hazards . . . 8
2.3 Surrounding Area . . . 8
2.4 Voltage . . . 9
2.5 Data safety . . . 9

3 Technical Specifications **10**
3.1 Control Unit . . . 10
3.2 Data Transmission . . . 10
3.3 Computer, Minimum Requirements . . . 11

4 Scope of Delivery **12**

5 Assembly **14**

6 Installation of Radio Transmission (Toshiba) **16**
6.1 Install Software & Drivers . . . 16
6.2 Software Configuration . . . 19
6.3 Configurate connection . . . 20

7 Installation of Radio Transmission (Conceptronic) **21**
7.1 Windows XP, 2000, ME und 98SE . . . 21
7.1.1 Install Software & Drivers . . . 21
7.1.2 Install Bluetooth-Dongle . . . 25
7.1.3 Configurate connection . . . 28
7.2 Windows Vista . . . 29
7.2.1 Install Bluetooth-Dongle . . . 29
7.2.2 Establish connection . . . 32

8 Control Elements **34**
8.1 Front View . . . 34
8.2 Back View . . . 35
8.3 Touchpad for Menu Navigation . . . 36

9 Operating Modes **37**
9.1 Activate Magnetometer . . . 37
9.2 Automatic Scan To PC . . . 37
9.3 Automatic Scan In Memory . . . 38
9.4 Manual Scan In Memory . . . 38
9.5 Transfer To PC . . . 39

10 Analysis and Evaluation of Measurements **40**
10.1 Metal or Mineralisation 40
10.2 General Procedure 42
10.3 Regulation of the Number of Impulses 43

11 Danger of Explosion during Excavation **45**

12 Maintenance and Services **46**

List of Figures

1 Scope of Delivery . . . 13
2 Put in the battery and connection of probe . . . 14
3 Connection of control chip and headphones . . . 14
4 Connection of Joystick and USB Dongle . . . 15
5 Connection of external power supply (optional) . . . 15
6 Bluetooth-Installation . . . 16
7 Bluetooth-Installation, Select Language . . . 16
8 Bluetooth-Installation, Start . . . 17
9 Bluetooth-Installation, Licence Agreement . . . 17
10 Bluetooth-Installation, Setup . . . 18
11 Bluetooth-Installation, Finish . . . 18
12 Bluetooth-Installation, Reboot . . . 19
13 Determining the given COM-Port . . . 19
14 . . . 20
15 Bluetooth-Installation . . . 21
16 Bluetooth-Installation, Select Language . . . 21
17 Bluetooth-Installation, Start . . . 22
18 Bluetooth-Installation, Licence Agreement . . . 22
19 Bluetooth-Installation, Destination Folder . . . 23
20 Bluetooth-Installation, Setup . . . 23
21 Bluetooth-Installation, Finish . . . 24
22 Bluetooth-Installation, Reboot . . . 24
23 Bluetooth-Installation, Plug in the Bluetooth-Dongle . . . 25
24 Bluetooth-Installation, Set up Bluetooth-Dongle . . . 25
25 Bluetooth-Installation, Bluetooth-Dongle has been installed . . . 25
26 Find out the assigned COM-Port . . . 26
27 Find out the assigned COM-Port . . . 26
28 Find out the assigned COM-Port . . . 27
29 USB-Connection, Enter PIN-Code . . . 28
30 USB-Connection, Confirm Access . . . 28
31 USB-Connection, Connection established . . . 28
32 Windows Vista, Install Bluetooth-Dongle . . . 29
33 Windows Vista, Set up Bluetooth-Dongle . . . 29
34 Windows Vista, Configurate Bluetooth-Dongle . . . 29
35 Windows Vista, Verify Bluetooth settings . . . 30
36 Windows Vista, Configurate serial COM-Port . . . 30
37 Windows Vista, Configurate serial COM-Port . . . 31
38 Windows Vista, Allow access . . . 32
39 Windows Vista, Set up Bluetooth-Dongle . . . 32
40 Windows Vista, Finish connection assistant . . . 33
41 Windows Vista, List of Bluetooth devices . . . 33
42 Front View . . . 34
43 Back View . . . 35
44 Touchpad . . . 36
45 Graphical representation of a measurement . . . 38

46 Comparison of object and mineral 41
47 Given manner 42
48 First measurement of an area 43
49 Control scan, Variant A 43
50 Control scan, Variant B 43
51 Effect of number of impulses and their distance 44
52 Comparison of small and high number of impulses 44

List of Tables

1 Technical Specifications (Control Unit) 10
2 Technical Specifications (Data Transmission) 10
3 Technical Specifiactions (Computer, Minimum Requirements) 11
4 Scope of Delivery 12

1 Preface

Dear customer,

in the first instance we want to thank you that you made your decision on a product of OKM Ortungstechnik GmbH.

With the Rover C you purchased a product which is based on a electromagnetic pulse method which can be used to locate anomalies in the target area. Thus the device is able to detect natural features such as formations of strata, cavities, groundwater level as well as sepulchers or buried objects such as pipes, tanks, boxes or suchlike.

The Rover C is able to locate, to document and to analyse buried objects with different structures, without making necessary any excavation. Particularly in areas next to the surface there are many advantages to geoelectric, seismic and magnetic procedures and it is further more a usefull complement to these methods. The Rover C has a facile and flexible handling and provides fast and easy reproducible results.

With our team of specialists we guarantee that our products are under recurrent control. Our specialists try to implement new developments in terms of further quality improvements for you.

Of course by selling our products we cannot guarantee that you really make a find during your research. The recognition of hidden objects and structures depends on a hugh number of factors - like you know. Determining factors are the dielectricity constant of the ground, the grade of mineralisation and the dimensions of an object relating to its depth. Specially in very wet soil, clay and sand with high conductivity of the ground, recording of the measured results can be falsified strongly.

With this product you purchased a device which stood the tests in regular operation like all other products of us. If you are interested in where our devices have gone into action please visit our homepage.

For our company it is necessary that we protect our developments within the framework of existing legislation to a patent or trademark registration. Therewith we offer you a higher warranty while using our products.

Please take your time consecutively, read this user‘s manual and familiarize yourself with the utilisation and operation of this Rover C.

2 Important Notes

Please read these operating instructions carefully and closely before using *Rover C* and its accessories! These instructions give information on how to use the device and point out potential sources of danger.

Rover C and its accessories serves for documentation and analysis of detect objects deposited and changes performed in the ground. The registered data of the ground structure will be transmitted to a PC for visual representation in a special software program using the components we offer. Any additional notes relating to this has to be observed. Please read attentively the manual according to the software you are using!

2.1 General Notes

Being an electronic device, *Rover C* has to be treated with the caution and care necessary when such devices are used. Any failure to observe the safety precautions given or any use for purposes other than the ones it is conceived for may result in a damage or destruction of the processing unit and connected components.

The device will get destroyed if it is opened improperly.

2.2 Possible Health Hazards

If used properly the device normally does not pose any health hazards. According to current scientific knowledge, the high-frequency signals are not harmful to the human body on account of their low power.

2.3 Surrounding Area

Having been transferred from a cold to a warmer place, the device should not be operated immediately afterwards. Any condensation, which may have formed, might cause the device to get destroyed. Avoid strong magnetic fields, which may occur in places such as near machines or loudspeakers, and avoid using a detector within a radius of 50 meters.

Metallic objects on the ground such as cans, doses, catches, nails, screw or others can influence negatively your measurement and have to be removed. Also you have to remove keys, telephones, chains and rings and all other magnetic and metallic objects from yourself.

2.4 Voltage

The power supply should not be outside the indicated range of values. Use only chargers, batteries and rechargable batteries which are included in the scope of delivery.

Never use the 230 Volt mains supply.

2.5 Data safety

There can be errors in the process of data collection if

- the range of the sender module is been exceeded,
- the power supply of the device is to low,
- the cables you are using are to long,
- other electronic devices sends out disturbances or
- atmospherics occurs (lightnings, . . .).

3 Technical Specifications

The following technical indications are medial values. During operation small variations are quite possible.

3.1 Control Unit

Dimensions (H x W x D)	430mm x 150mm x 260mm
Weight	about 3kg
Voltage	9 – 12 VDC
Processor	Motorola, 4 MHz
Data Memory (internal)	about 1.500 measured values
Operating Temperature	0°C – 50°C
Storage Temperature	-20°C – 60°C
Air Humidity	5% – 75%
Waterproof	No

Table 1: Technical Specifications (Control Unit)

3.2 Data Transmission

Technology	Bluetooth
Frequency	2.4 – 2.4835 GHz
Maximal Data Transmission Rate	1 Mbps
Receiving Sensitivity	-85 dBm
Maximal Range	about 100 meters

Table 2: Technical Specifications (Data Transmission)

3.3 Computer, Minimum Requirements

The computer is not part of the scope of delivery. The indicated values should help you for a correct selection of a suitable computer for analysis of your measured results.

CD-ROM Drive	minimum 4x
COM-Port (Data Transmission)	USB
Free Memory	minimum 20 MB
Working Memory (RAM)	minimum 128 MB
Graphic Card	minimum 64 MB, OpenGL-compatible
Operating System	Windows 98SE, Me, 2000, XP

Table 3: Technical Specifiactions (Computer, Minimum Requirements)

4 Scope of Delivery

In the following section you can find all standard equipment. The scope of delivery can be different in some circumstances because of some optional accessories which should not be included in the basic equipment.

1	Control Unit
1	Probe
1	Battery 9V
1	Charger for Battery 9V
1	USB Bluetooth Dongle
1	USB Setup CD
1	3D Software (Standard)
1	Joystick
1	Control Chip
1	Headphones
1	User‘s Manual
1	Carrying Case

Table 4: Scope of Delivery

Beware that pictures in this manual could be different to delivered parts.

Figure 1: Scope of Delivery

5 Assembly

In this section is explained how to assemble the device and how to prepare a measurement.



Figure 2: Put in the battery and connection of probe

Figure 2 shows how to put in the 9V battery in the provided battery box and how to connect the probe with the main unit. Do it without any unnecessary application of force!



Figure 3: Connection of control chip and headphones

Figure 3 shows how to plug in the control chip in the appropriate connection of the main unit. Without this control chip the device cannot operate. Also it is visible where to connect the headphones.

Figure 4: Connection of Joystick and USB Dongle

Figure 4 indicates which connection has to be used for joystick. Please take care not to exchange both elements, otherwise the device can get damaged. Also you can see how to connect the Bluetooth Dongle to the USB-Port of your computer. Additional information about the correct usage and installation of the USB driver you can find in section **??** on page **??**.

Figure 5: Connection of external power supply (optional)

In figure 5 you can see how the external power supply has to be connected. Please take care that you use the 12V output of the external power supply for the correct cable connection. The external power supply is not part of the standard scope of delivery of your device.

6 Installation of Radio Transmission (Toshiba)

This section describes the installation of the USB Bluetooth Dongle. Consider that the represented figures not necessarily agree with the current version of your operating system or the version of your USB installation.

The instructions in this chapter are only valid for the Toshiba usb-drivers. If you are using the Conceptronic usb-drivers, please read chapter 7.

6.1 Install Software & Drivers

Now it is time to install the software and driver on your system. Therefore you have to insert your Bluetooth CD into the CD ROM drive of your computer. If the CD does not start automatically, please double click on Desktop and then double click on the symbol of your CD ROM drive. With a further double click on file `setup.exe` you start the installation.

Figure 6: Bluetooth-Installation

The first window of your installation will open. Click here on the entry *Toshiba Driver* and follow the instructions on the screen.



Figure 7: Bluetooth-Installation, Select Language

First there is a possibility to select the language of the installation. Click on *OK*, to change to the installation dialog from figure 8.


Bluetooth Stack for Windows by Toshiba - InstallShield Wizard
Welcome to the InstallShield Wizard for Bluetooth Stack for Windows by Toshiba
The InstallShield(R) Wizard will install Bluetooth Stack for Windows by Toshiba on your computer. To continue, click Next.
< Back
Next >
Cancel

Figure 8: Bluetooth-Installation, Start

Now simply click on *Next*, to continue the installation. A dialog like in figure 9 appears on your screen.


Bluetooth Stack for Windows by Toshiba - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
TOSHIBA CORPORATION
End User License Agreement
This End User License Agreement ("EULA") is a legal agreement between you and TOSHIBA CORPORATION ("TOSHIBA") with regard to the copyrighted Software provided with this EULA.
I accept the terms in the license agreement
I do not accept the terms in the license agreement
InstallShield
< Back
Next >
Cancel

Figure 9: Bluetooth-Installation, Licence Agreement

Select the option *I accept the terms in the licence agreement* and confirm it with a click on *Next*.


Bluetooth Stack for Windows by Toshiba - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

Figure 10: Bluetooth-Installation, Setup

Click now on the button *Install*, to start to copy the files. Afterwards you will be refered that the installation process can take about 15 minutes. Answer this question with a click on *OK*. If you did not connect the Bluetooth Dongle until now you will be asked to do so during the installation of the driver. Now wait until the installation is finished and all files has been transferred to your computer.


Bluetooth Stack for Windows by Toshiba - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed Bluetooth Stack for Windows by Toshiba. Click Finish to exit the wizard.
< Back
Finish
Cancel

Figure 11: Bluetooth-Installation, Finish

As soon as the installation is finished, a dialog as in figure 11 appears. Click on the button *Finish*.


Bluetooth Stack for Windows by Toshiba Installer Infor...
You must restart your system for the configuration changes made to Bluetooth Stack for Windows by Toshiba to take effect. Click Yes to restart now or No if you plan to restart later.
Yes
No

Figure 12: Bluetooth-Installation, Reboot

To terminate the installation you have to reboot your computer. A message like in figure 12 will appear. Confirm it with a click on the button *Yes*.

6.2 Software Configuration

To find out on which COM-Port your Bluetooth connection is been installed, click on Start → Settings → Control Panel. Double click the entry *Bluetooth Local COM*. A dialog will open like it is represented in figure 13.


Bluetooth Local COM
Vorhandene COM-Ports:
Port Beschreibung Eigentümer
COM1 Kommunikationsanschluss (C... System
COM2 Kommunikationsanschluss (C... System
COM6 Toshiba BT Port (COM6) LocalCOM-Client
COM7 Toshiba BT Port (COM7) LocalCOM-Server[SerialPort(TOSHIBA Lo
COM10 Toshiba BT Port (COM10) Information Exchanger
COM11 Toshiba BT Port (COM11) Information Exchanger
COM12 Toshiba BT Port (COM12) Information Exchanger
COM13 Toshiba BT Port (COM13) Information Exchanger
COM14 Toshiba BT Port (COM14) Information Exchanger
COM20 Toshiba BT Port (COM20) HSP Manager
COM21 Toshiba BT Port (COM21) HSP Manager
Hinzufügen
Löschen
OK

Figure 13: Determining the given COM-Port

There you can find the entry *LocalCOM-Server[SerialPort(TOSHIBA LocalCOM)]*, which indicates on which COM-Port your Bluetooth Dongle has been installed. This COM-Port you always have to indicate for the data transmission to the software program.

6.3 Configurate connection

After installation and configuration of your Bluetooth connection you should test if the data transmission from your measuring instrument to the computer is working correctly.

Be sure that the USB Dongle is attached to your computer. Take your measuring instrument and power on the device. Select a operating mode, which includes the direct data transmission to PC. Additional information on direct data transmission to PC you can find in section 9 on page 37.



Figure 14:

As soon as you confirm your selected operating mode the device will try to get a radio connection to the computer. If this connection is successful a message like in figure 14 appears.

In this dialog you have to enter `OKM`. It is neccessary to write in capital letters!

7 Installation of Radio Transmission (Conceptronic)

This section describes the installation of the USB Bluetooth Dongle. Consider that the represented figures not necessarily agree with the current version of your operating system or the version of your USB installation.

The instructions in this chapter are only valid for the Conceptronic usb-drivers. If you are using the Toshiba usb-drivers, please read chapter 6.

7.1 Windows XP, 2000, ME und 98SE

7.1.1 Install Software & Drivers

Now it is time to install the software and driver on your system. Therefore you have to insert your Bluetooth CD into the CD ROM drive of your computer. If the CD does not start automatically, please double click on Desktop and then double click on the symbol of your CD ROM drive. With a further double click on file `autorun.exe` you start the installation.



Figure 15: Bluetooth-Installation

The first window of your installation will open. Click here on the entry *1 Install drivers and application software* and follow the instructions on the screen.

Wählen Sie eine Setup-Sprache aus
Wählen Sie die Sprache dieser Installation aus der unten aufgeführten Auswahl aus.
Deutsch (Deutschland)
OK
Abbrechen

Figure 16: Bluetooth-Installation, Select Language

First there is a possibility to select the language of the installation. Click on *OK*, to change to the installation dialog from figure 17.


BlueSoleil - InstallShield Wizard
Welcome to the InstallShield Wizard for BlueSoleil
The InstallShield(R) Wizard will install BlueSoleil on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

Figure 17: Bluetooth-Installation, Start

Now simply click on *Next*, to continue the installation. A dialog like in figure 18 appears on your screen.


BlueSoleil - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
Bluesoleil End User License Agreement
NOTICE TO USER: PLEASE READ THIS AGREEMENT CAREFULLY. THE BLUESOLEIL END USER LICENSE AGREEMENT (AGREEMENT) IS A VALID AND BINDING AGREEMENT BETWEEN YOU, AS A USER, AND IVT CORPORATION (IVT). BY USING ALL OR ANY PORTION OF THE SOFTWARE, YOU ACCEPT ALL THE TERMS AND CONDITIONS
I accept the terms in the license agreement
I do not accept the terms in the license agreement
Print
InstallShield
< Back
Next >
Cancel

Figure 18: Bluetooth-Installation, Licence Agreement

Select the option *I accept the terms in the licence agreement* and confirm it with a click on *Next*.



Figure 19: Bluetooth-Installation, Destination Folder

Inside the dialog from figure 19 you have the possibility to select another destination folder. Normally there is no changing necessary. Click only on the button *Next*.


BlueSoleil - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

Figure 20: Bluetooth-Installation, Setup

Click now on the button *Install*, to start to copy the files. Now wait until the installation is finished and all files has been transferred to your computer.



Figure 21: Bluetooth-Installation, Finish

As soon as the installation is finished, a dialog as in figure 21 appears. Click on the button *Finish*.


BlueSoleil Installer Information
You must restart your system for the configuration changes made to BlueSoleil to take effect. Click Yes to restart now or No if you plan to restart later.
Yes
No

Figure 22: Bluetooth-Installation, Reboot

To terminate the installation you have to reboot your computer. A message like in figure 22 will appear. Confirm it with a click on the button *Yes*.

7.1.2 Install Bluetooth-Dongle

After you have reboot the computer the message from figure 23 appears on your screen. Now you have to plug in the Bluetooth-Dongle into your computer.



Figure 23: Bluetooth-Installation, Plug in the Bluetooth-Dongle

Now your computer tries to install automatically the Bluetooth-Dongle. Wait until a dialog window like in figure 24 appears on your screen. Click on the button *OK*.


Welcome to Bluetooth
Welcome to Bluetooth
General
Please set your Bluetooth device name and device type. This information will be shown to other Bluetooth devices.
Device Address: 00:80:5A:46:11:82
Device Name:
Device Type: Desktop
Security
Your security level is 'Medium' now. Other Bluetooth devices must provide a Bluetooth passkey before connecting with your computer. If you do not want to have security authentication, uncheck 'Use security level Medium.'
Use security level Medium
OK

Figure 24: Bluetooth-Installation, Set up Bluetooth-Dongle

After a successful set up of the Bluetooth-Dongle the message from figure 25 appears on your screen.

Figure 25: Bluetooth-Installation, Bluetooth-Dongle has been installed

To find out on which COM-Port the Bluetooth connection has been installed you have to click with the right mouse button on the Bluetooth symbol in the task bar. A dialog window like in figure 26 will appear.

Figure 26: Find out the assigned COM-Port

If you click here on the entry *Display* a window like represented in figure 27 will open. Select in the menu *View* the option *Service Window*.



Figure 27: Find out the assigned COM-Port

An image like in figure 28 is represented. Behind the indication *Serial Port A* you can read the number of the assigned COM-Port. In this figure it is *COM7*, this can be different on your computer!



Figure 28: Find out the assigned COM-Port

7.1.3 Configurate connection

After installation and configuration of your Bluetooth connection you should test if the data transmission from your measuring instrument to the computer is working correctly.

Be sure that the USB Dongle is attached to your computer. Take your measuring instrument and power on the device. Select a operating mode, which includes the direct data transmission to PC. Additional information on direct data transmission to PC you can find in section 9 on page 37.


Enter Bluetooth Passkey
A remote device needs a Bluetooth Passkey to create Paired relationship for future connections. Please use the same passkey on this device and on the remote device:
OK
Cancel
Remote Device:
Address 00:0B:53:13:81:6B
Passkey: ***
Time Left: 18 s

Figure 29: USB-Connection, Enter PIN-Code

As soon as you confirm your selected operating mode the device will try to get a radio connection to the computer. If this connection is successful a message like in figure 29 appears. In this dialog you have to enter `OKM`. It is neccessary to write in capital letters! Confirm this entry by a click on the button *OK*.


Bluetooth Service Authorization
Bluetooth device "00:0B:53:13:81:6B" is attempting to access Bluetooth Serial Port A service. Click Yes to allow this device to access this service.
Yes
No
Always allow this device to access this service.
Time Left: 22 s

Figure 30: USB-Connection, Confirm Access

Another window will open where you mark the entry *Allways allow this device to access this service* and confirm this entry by a click on *Yes*.

Figure 31: USB-Connection, Connection established

The message from figure 31 indicates that the connection is established. Now you have set up successfully your Bluetooth connection.

7.2 Windows Vista

For Windows Vista there are no additional drivers necessary. The basic functions are already provided by the operating system. To install the Bluetooth-Dongle on your Windows Vista system, please read the instructions in the following subsection!

7.2.1 Install Bluetooth-Dongle

Power on your computer and wait until Windows Vista is completely booted. After you signed up for your Windows Vista system plug in the Bluetooth-Dongle into a free USB slot. The message from figure 32 appears on your screen.



Figure 32: Windows Vista, Install Bluetooth-Dongle

Wait a little moment until the installation of the Bluetooth-Dongle is completed successfully and the message from figure 33 appears on your computer screen.



Figure 33: Windows Vista, Set up Bluetooth-Dongle

To use the Bluetooth-Dongle with your device, you have to apply a serial COM-Port. Therefore please click with the right mouse buttom on the Bluetooth symbol on the down right side of your computer screen! A dialog similiar to figure 34 will open. Click with the left mouse button on the entry *Open Bluetooth settings*.



Figure 34: Windows Vista, Configurate Bluetooth-Dongle

The dialog window from figure 35 will open. Click with the left mouse button on the tab *Options* and compare the settings of your computer with those from the figure. After that please click on the tab *COM-Ports*.
To transfer the measured data from your device to the computer, you have to establish now the serial COM-Port. The figure 35 (right side) shows the relevant dialog window. Click with the



Figure 35: Windows Vista, Verify Bluetooth settings

left mouse button on the button *Add*. Another dialog window like represented in figure 36 will open.



Figure 36: Windows Vista, Configurate serial COM-Port

In this dialog you only have to select option *Incoming (Device initiate connection)* and confirm your selection by a click on the button *OK*. Automatically a serial COM-Port will be created and a Port refered. In this tutorial the Port *COM3* has been refered. This Port *COM3* has to be entered later in the software, to transfer measured data to your computer.



Figure 37: Windows Vista, Configurate serial COM-Port

Again, in figure 37 the allocation of the serial COM-Port *COM3* is represented. The installation of the Bluetooth-Dongle is now completed. The next step is to establish a test connection, to control the connectivity.

7.2.2 Establish connection

Be sure that the Bluetooth-Dongle is plugged into your computer. Now take your measuring instrument and power it on. Select an operating mode which supports the direct data transfer to your PC. Detailed information you can find in section 9 on page 37. As soon as you confirmed this function on your device, a radio connection to your pc will be established. If it is successfull the dialog from figure 38 appears.


Ein Bluetooth-Gerät erfordert eine Verbindung mit dem Computer.
Klicken Sie auf diese Meldung, im die Verbindung zuzulassen.
DE
15:46

Figure 38: Windows Vista, Allow access

Click with the left mouse button inside this message to enter the PIN-Code. A dialog like in figure 39 appears on your computer screen.

Assistent zum Hinzufügen von Bluetooth-Geräten
Geben Sie den Hauptschlüssel für das Bluetooth-Gerät ein.
OKM
Verwenden Sie denselben Hauptschlüssel, den Sie für das Gerät eingegeben haben.
Hauptschlüssel:
Sie sollten immer einen Hauptschlüssel verwenden, es sei denn, das Gerät unterstützt keinen. Es wird empfohlen, dass der Hauptschlüssel zwischen 8 und 16 Ziffern lang ist. Je länger der Hauptschlüssel, desto sicherer ist die Übertragung.
< Zurück
Weiter >
Abbrechen

Figure 39: Windows Vista, Set up Bluetooth-Dongle

There please enter the PIN-Code `OKM`. Take care to use capital letters! Confirm the entry by aclick on the button *Next*.

Assistent zum Hinzufügen von Bluetooth-Geräten
Fertigstellen des Assistenten
Das Bluetooth-Gerät wurde an den Computer angeschlossen. Der Computer und das Gerät können kommunizieren, wenn sich beide in Reichweite befinden.
Klicken Sie auf "Fertig stellen", um den Vorgang abzuschließen.
< Zurück
Fertig stellen
Abbrechen

Figure 40: Windows Vista, Finish connection assistant

After a connection has been established the dialog from figure 40 appears. Just click on the button *Finish* to finish the connection assistant.



Figure 41: Windows Vista, List of Bluetooth devices

To find out the current status of your Bluetooth-Dongle click with the right mouse button on the Bluetooth symbol inside the down right corner of your screen. In the following menu (see figure 34 on page 29) please click with the left mouse button on the entry *Open Bluetooth settings*. A dialog like in figure 41 shows all existing devices. As soon as one of these devices has established a connection it will be indicated by the supplement *Connected*.

8 Control Elements

In this section you will learn more about the fundamental use of all control elements for this measuring instrument. All connections, inputs and outputs are explained in detail.

8.1 Front View

Figure 42 shows the front side of the control unit.



Figure 42: Front View

The Power On and Off Button is used to switch on and off the control unit. Before operating with your device you have to put in the delivered 9V battery or connect the optional external power supply and power it on.

The LCD Display indicates how often the device was powered on. This display is only of interest for our repair and maintenance service.

The Start Button is used to start your measurement and to release manually every impulse in the appropriate mode.

The Input for Joystick is used to connect the delivered joystick. He fullfils the same functions like the Start Button,but is more comfortable and can facilitate the measurement procedure.

The Input for Headphones the delivered headphones can be connected.

The Connection for External Power Supply the external power supply which is optional available can be connected.

8.2 Back View

Figure 43 shows the back side of the control unit with all connections.



Figure 43: Back View

The Compartment for 9V Battery is used to put in the charged 9V battery.

In the Connection for Probe the delivered probe has to be plugged into the control unit.

The Connection for Control Chip is used to connect a control chip. This chip is absolutely necessary to operate with this measuring instrument.

The Antenna for Bluetooth is used for the data transmission to a PC.

8.3 Touchpad for Menu Navigation

The top of the device is including a touchpad like in figure 44. With this touchpad you can navigate to the different operating modes in the menu.



Figure 44: Touchpad

With keys ⬆ and ⬇ you can select every operating mode. To confirm your selection press OK.

9 Operating Modes

In this section you will learn more about the different operating modes of the device. Every function is been explained in particulary in its proper subsection. The right selection of an operating mode depends primarily of your planned measurement. So for example there are some special functions which have to be used for a first measurement in a unknown area to get a general overview, against which others are more suitable for a detailed search and analysis with a special processing software program.

The device prossesses the following operating modes:

- **Activate Magnetometer**
  Activate the magnetometer function.
- **Automatic Scan To PC**
  Send measured values directly to a PC for analysis.
- **Automatic Scan In Memory**
  Store measured values in the internal memory of the device.
- **Manual Scan In Memory**
  Send measured values manuelly in the internal memory of the device.
- **Transfer To PC**
  Send measured values from internal memory of the device to a connected PC.

Via a touchpad on the top of your device you can select and confirm your appropriate operating mode.

9.1 Activate Magnetometer

In operating mode „*Activate Magnetometer*“ the device will activate the integrated magnetometer mode. This mode allows you to notice acoustically the existing field strength.

The higher the field strength the higher will be the acoustic signal. In this operating mode it is easily possible to find metalic objects (in particulary iron objects) close to the surface.

9.2 Automatic Scan To PC

With this operating mode you can measure until a depth of 18m [1].

Immediately after confirming the operating mode by pressing the key Activate operating mode, the message *Connecting with Computer ...* will appear on the display of your device. This procedure can take a few seconds. Further information about the connection establishment via Bluetooth you can find in section **??** on page **??**. Afterwards you will be asked to press the Start button.

[1] The total penetration depth is strongly depending on the type of soil. In high mineralized areas the penetration depth can be minimized.

If the measured values are transferred to the PC, automatically a graphical representation will be created. An example you can find in figure 45.



Figure 45: Graphical representation of a measurement

The graphical representation should mainly include green color values which represent normal ground. In this graphic could be included red or blue objects. Normally metallic objects are represented in red color and cavities, water deposits and diggings always in blue color. Beware that mineralisations in the ground also could be in red color. How to recognize minerals from „*real*“ metals, you can read in section 10.1 on page 40 or in your software manual.

Please read attentively section 10.2 on page 42, where the principle procedure of a graphical measurement is explained.

9.3 Automatic Scan In Memory

This operating mode is identically to function „*Automatic Scan To PC*“, but the measured values will be stored in the internal memory of the device and not transferred directly to a PC.

After having finished your measurement all data can be transferred to a PC with menu option „*Transfer To PC*“ .

Read also attentively section 10.2 on page 42, where the principle procedure of a graphical measurement is explained in detail.

9.4 Manual Scan In Memory

This operating mode is identically to function „*Automatic Scan To PC*“, but the measured values will be stored in the internal memory of the device and not send directly to a PC. Also every single impulse (memory of measured values) has to be activated manually. Therefore you can use the delivered Joystick or the Start button.

After having finished your measurement you can transfer all data to a connected PC with operating mode „*Transfer To PC*“ .

Please read also attentively section 10.2 on page 42, where the principle procedure of a graphical measurement is explained in detail.

9.5 Transfer To PC

With operating mode „*Transfer to PC*“ measured values can be transmitted from the internal memory of the device to a computer. Therefore it is necessary that the software has to be prepared before starting the transmission. Only if all preparations of the software are made correctly and the software program is ready to receive the measured data you can confirm this function. Further information about a correct preparation of the software program you can find in the manual of your software product.

Immediately after confirming the operating mode by pressing the key Activate operating mode, the message *Connecting with Computer ...* will appear on the display of your device. This procedure can take a few seconds. Further information about the connection establishment via Bluetooth you can find in section **??** on page **??**. Afterwards you will be asked to press the Start button.

The measured data will now be transmitted to your computer at one time.

10 Analysis and Evaluation of Measurements

Before measurement you have to know what kind of objects or cavities you are looking for and if the area you choose is suitable for this. Measurement without a plan will not give you the results you would like. For this reason please consider the following indications:

- What are you looking for (graves, tunnels, buried objects, ...)? This question has its effects on your concrete manner to measure an area. If you are looking for big objects you can enlarge your distance between the measure points (impulses), for small objects use small distances (see section 10.3 on page 43).
- Inform yourself about the area you select for measurement. Is it usefull to search at this place? Are there historical indications, which confirm your speculations? What type of soil is on this area? Are there good conditions for data recording?
- Your first measurement in a unknown area has to be large enough to get representative values (f. ex. 20 impulses, 20 search lines).
- What is the form of the object you search? If you are looking for an angular metal box, the identified object in your graphic should have a form according to this.
- To get exact values concerning the depth measurement, the object has to be in the centre of the graphic, which means it has to be framed by normal reference values (normal ground). If the object is on the side of the graphic and not totally visible a correct depth measurement is not possible.
- There should not be more than one object in a graphic. This will influence the exactness of depth measurement.
- You should do at least two control scans to get sure about your results. So you also can recognize and isolate mineralized ground (see section 10.1 on page 40).

10.1 Metal or Mineralisation

At the beginning it is not always easy to make a difference between real objects and mineralized ground. In principle metals are represented in red color, but mineralized accumulations can also include red signals.

Here some advice how you can differentiate between a real object and a mineralisation:

- **Form**
  If the object represented in your graphic has a special form (f. ex. rectangle, circle, ...), you can conclude of a possible real found.
- **Color**
  If there are many yellow and orange color values around the object, it will be probably a mineralisation.
- **Depth**
  With a small depth of about 0,10m or 0,40m there is a high possibility that there is only a mineralisation of the ground.

- **Color Filter**
  If position and form of the object are changing with the use of the color filter it is probably a mineralisation.

- **Control Scan**
  If position, depth and form of the object stay nearly the same, also in further control scans you can conclude of a real object. Also if some graphics look similiar you always have to compare all indications.

Figure 46 shows a real object (left side) and a mineralized accumulation (right).



Figure 46: Comparison of object and mineral

10.2 General Procedure

The main rule for scanning an area is:

The more exactly you scan an area
the better will be your graphical evaluation.

You have to scan in a given manner that the software can calculate the measured values in the right way. Your device has following possibilities:

- **Zig-Zag**

Figure 47 shows all different ways of scanning in a scheme. The measurement starts at your starting point ① and ends at point ②.



Figure 47: Given manner

If you have finished one scan line, the next line has to be on the *left* side. Do not change the direction of your probe.

The more you repeat your scanning above a possible object (control scans), the better you can decide afterwards if it is a real object or not. Temperature, other radio transmission, sun energy, mineralisation of the ground, loam, salt, water, etc. can influence negatively the measure results.

Before you start to dig, take your time to do some control scans. Repeat exactly the same scan about 3 - 5 times, to be sure about your results. Only if all these graphics have almost the same values you can be sure about your results.

Figure 48 is a graphical representation of a measured area. The blue rectangle marks a possible object in the ground.

To be absolutely sure that there is an object in the ground you have to do a control scan. Measure exactly the same area, same starting point and the same number of impulses and lines. Take also the same distance between the measure points. Figure 49 and 50 shows two possible measurements.

It is easy to recognize that the control scan in figure 49 is totally different from the first measurement in figure 48. This means only a mineralisation of the ground, not a concrete metalic object.



Figure 48: First measurement of an area



Figure 49: Control scan, Variant A

Even if the control scan in figure 50 is not exactly the same to the first one, you can see that the blue marked parts show nearly the same values. This is a reference for the existence of an object.



Figure 50: Control scan, Variant B

Before you can determine the depth of the detected object you have to scan a further image. It only should cover the blue marked area. All other metals and mineralized ground should be ignored because it would disturb the measurement. After this you can determine the correct depth.

10.3 Regulation of the Number of Impulses

There is no special rule for the number of impulses. But there are different aspects which has to be considered. These are for example

- the length of your measured area and
- the size of the objects you are searching.

The optimal distance between two impulses is about 20cm until 30cm. The smaller the distance between two impulses is the more exactly will be the graphical representation. If you are looking

for small objects you have to select a small distance, for big objects you can increase the distance between each impulse.

Figure 51 shows the effects of the distance and the number of impulses per scan line for some objects.



Figure 51: Effect of number of impulses and their distance

Figure 52 shows the difference between very few impulses (left side) and much more impulses on the same scan line length (right side). The second record (right side) shows much more details and also smaller objects can be seen.



Figure 52: Comparison of small and high number of impulses

Do not hesitate to record more measurements with different numbers of impulses. For example you can scan a large area before doing a second detailed precision measurement. Especially for the search of bigger objects you can proceed like this. With this manner you can measure relatively fast a large area and afterwards you can record the interesting subsection.

Further information about the graphical analysis you can find in the appropriate software manual.

11 Danger of Explosion during Excavation

Unfortunately, the last two world wars also made the ground in many places of the world a potentially explosive scrap heap. A host of those lethal relics are still buried in the ground. Do not start digging and hacking for an object wildly when you receive a signal of a piece of metal from your device. Firstly, you might indeed cause irreparable damage to a truly rare find, and secondly, there is a chance that the object reacts in an insulted way and strikes back.

Note the colour of the ground close to the surface. A red or reddish color of the ground is an indicator of rust traces. As regards the finds themselves, you should definitely pay attention to their shape. Curved or round objects should be a sign of alarm, especially if buttons, rings or little pegs can be identified or felt. The same applies to recognizable ammunition or bullets and shells. Leave that stuff where it is, do not touch anything and, most importantly, do not take any of it home with you. The killing machines of war made use of diabolical inventions such as rocker fuses, acid fuses and ball fuses. Those components have been rusting away in the course of time, and the slightest movement may cause parts of them to break and be triggered. Even seemingly harmless objects such as cartridges or large ammunition are anything but that.

Explosives may have become crystalline over time, that is, sugar-like crystals have formed. Moving such an object may cause those crystals to produce friction, leading to an explosion. If you come across such relics, mark the place and do not fail to report the find to the police. Such objects always pose a danger to the life of hikers, walkers, farmers or children.

12 Maintenance and Services

In this section you will learn how to maintain your measuring instrument with all included accessories to keep it in good condition a long time and to get good measuring results.

The following list indicates what you absolutely should avoid:

- penetrating water
- strong dirt and dust deposits
- hard impacts
- strong magnetic fields
- high and long lasting heat effect

If you want to clean your device please use a dry rag of soft material. To avoid any damage you should transport the device and accessories always in the appropriate carrying cases.

Beware that all batteries and accumulators are always charged fully while operating with your system. You should only load the batteries when they are completely discharged no matter if you are working with the external power supply or with the internal accumulators. In this way a long durability of the used batteries is guaranteed.

To load the external and internal batteries you have to use only chargers which are part of our scope of delivery.

Index

Activate operating mode, 37, 39

Bluetooth, 16, 21
Bluetooth-Dongle, 25, 29, 31–33

Dongle, 16, 21

Headphones, 34

Joystick, 34, 38

PIN-Code, 32

Start Button, 38
Start button, 37–39

USB, 16, 21